



To ensure a perfect sealing and the proper functioning of the sampling equipment, it is imperative to close and fix scratches.

- **Installation of the SOCPROTHERM-TYPE-10 cover (for pressure regulator)**



- 1- Open the Velcro tabs of the cover.
- 2- Install the cover on the regulator and attach the Velcro tabs.

