> ThermOmegaTech[®] **INSTALLATION INSTRUCTIONS** HAT & TV/HAT

IMPORTANT: Before installation, please read and understand this sheet.

HAT or

TV/HAT

REMEMBER: These valves are fully open at their stated temperature and fully closed at approximately 10°F higher. Unless otherwise stated, these valves are supplied at their standard Cv or flow rate. Smaller or larger Cv's are available on request. Outflow temperatures will be the same regardless of pressure and the amount of backup will depend on heat loss. These valves will not cycle, but will modulate, which makes them ideal for heat trace applications where over-temperature is

undesirable. If condensate outflow is to be used to warm or freeze protect a small device, you must provide several feet of bare tubing ahead of (upstream of) the valve to provide the condensate. A #20 mesh strainer is recommended to use with all port sizes.

AS A STEAM TRAP REPLACEMENT:

The HAT and TV/HAT can be used to efficiently trace any number of critical components. Because

(20.7 BAR) may be used without worry that the tracer will be too hot for the process or component.

The *HAT* and *TV/HAT* can be used to replace some traps. In general, they may be used in any light load situation, such as: Steam tracing, ahead of block valves in steam lines, and start-up vents for water hammer plagued systems.

NOTE: In the condensate return header application illustrated, the *HAT* and *TV/HAT* must be used with a check valve downstream if the header is not at atmospheric pressure.





CONDENSATE RETURN HEADER

HAT for

FREEZE

PROTECTION

TRACING A CONTROL VALVE OR PUMP CASE:

TV/HAT STEAM TRAP

TRACE DELICATE INSTRUMENTS IN FLEXIBLE OR RIGID **ENCLOSURES:**

Together with the *TV/SC-I* (as shown in the accompanying

illustration) or ITCH kit, the TV/HAT can be used to provide accurate temperature control in an instrument enclosure or analyzer housing. The TV/HAT on the steam inlet keeps the supply line hot right up to the enclosure. For maximum economy, the **TV/HAT** on the outlet removes the condensate in the heater only when it falls below the desired temperature. HAT or TV/HAT valves may also be used to trace delicate sample lines without worry of over-temperature or available steam pressure.

Therm-Omega-Tech® also manufactures HAT valves in temperature ranges that will regulate steam or fluid outflow temperature for many applications, including freeze protection of: Safety showers and/or eyewash stations, pipe runs, water mains; backup protection of traced mains, or for bare pipe runs from an insulated and traced main. Reverse acting models (HAT/RA, HAT/SP) that provide over-temperature (scald) protection and cooling water control are also manufactured. Available pipe sizes: 1/2" and 3/4" NPT as well as 1/4", 3/8" and 1/2" tube compression fittings. Various Cv's are available also.

CAUTIONS:

Do not over-tighten connections * Tighten tube compression fittings per standard practice* Always test after installation and before use * Always test before winter and summer seasons * Test at regular intervals

WARNING: This product can expose you to chemicals, for example lead, nickel, acrylonitrile, which are known to the State of CA to cause cancer, birth defects, or reproductive harm. For more information, go to www.P65Warnings.ca.gov

Warranty information disclosed at www.thermomegatech.com/terms-conditions/

HAT-TV IMI REV: 1/31/20